

## The instruction for solid pin

Picture



Remark

Be going to crimping



The Stripped cable need to be put into the pin directly



Then using crimping tool to crimp



Crimp well (but it can not be welded)

## The instruction for hollow pin

picture



Remark

The Stripped cable need to be put into the pin directly



crimping



Well done, but we can also use welding, because welding could be made pin and cable more compatible and more maedsaed, please know pictures as following:



After Crimping, then using welding, welding would make better connect (cable connect pin)



well done

